

Reservedeler Sunrise

HMS-artnr	Beskrivelse	Leverandørens artnr
030791	Hjul XL stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus dia10	801360
030799	Bremsefot stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus dia3.2	801264
168034	Ryggstolpe Medic/Comfort stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 kompl lav rygg	801088
174934	Ryggstolpe Medic/Comfort stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus kompl høy rygg	801737
176892	Ben Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus brems understell hjul dia12,5 kpl	803504
176893	Ben Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus brems understell hjul dia15 kpl	803505
176895	Pedal Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus brems understell bremseaksel dia2	802865
176896	Feste bremsepak Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus understell just 7 trinn	802800
176967	Hjul SL stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus dia10 kulelager	801638
177091	Feste Medic stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus ryggvinkling	802859
177092	Mekanisme ryggvinkling Medic stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700	801083
177093	Mekanisme ryggvinkling Medic stol arbeid Real 9300 Plus/9400 S d11,2 h20 Classic Ergomedic	801923
177094	Mekanisme ryggvinkling Medic stol arbeid Real 9300 Plus/9400 S d15,5 h20 Classic Ergomedic	801922
177095	Mekanisme ryggvinkling Medic stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9700 Plus/Real 9800 Plus XL d15,5 h34	801084
177118	Ryggstolpe Medic Ergomedic stol arbeid Real 9300 Plus/9400 S kompl lav rygg liten	801928
177211	Setehøyderregulering stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800	803117
204788	Skruer stol arbeid 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus montering	803268
204789	Skruer stol arbeid 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus montering rygg	803270
204790	Skruer stol arbeid 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus montering	803269
204795	Gassfjær stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus 250N	801145
205673	Mekanisme ryggvinkling stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real	800842
206357	Feste bord Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus	803156
216412	Bryter stol arbeid Real 9100 Plus/9400/Real 9800 Plus 4 funksjoner m/tunge 24V 1G	804552
216413	Håndkontroll stol arbeid Real 9100 Plus/Real 9400 Plus/Real 9800 Plus 4 funksjoner 24V 1G	804490
216417	Holder stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	801200
216418	Festebånd stol arbeid Real 9100 Plus/Real 9400 Plus/Real 9800 Plus batteri i70 b1,8	801258
216425	Bryter stol arbeid Real 9100 Plus/9400/Real 9800 Plus el funksjon m/tunge	802692
216426	Feste stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus bremsepak	802799
216427	Bremseben Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus understell	802810
216428	Festeklemme Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800	802874
216430	Festebakke stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	802964
216431	Stjerneratt Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803004
216432	Stjerneratt Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803005
216433	Låsespak Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803006
216434	Stjerneratt Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803007
216435	Vippebryter stol arbeid Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus rød tunge	803103
216436	Setevinkelregulering Plus stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus spak inkl vire under	803265
216437	Skruer stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803271
216438	Sylinderbolt stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803508
216439	Aktuator arbeidsstoler coxistoler Real 9100 Plus/Real 9400 Plus/Real 9800 Plus m48x50 24V	803607
216441	Kjørehåndtak stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	803903
216442	Feste stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus H-sele	804184
216445	Batterilader stol arbeid Real 9100 Plus/9400/Real 9800 Plus 24V	804428
216450	Betjeningsboks Plus stol arbeid Real 9100 Plus/9400/Real 9800 Plus rygg setevinkel kpl	804486
216451	Betjeningsboks Plus stol arbeid Real 9100 Plus/9400/Real 9800 Plus setehøyde brems kpl	804487
216452	Aktuator stol arbeid Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus ryggvinkel 24V	804488
216453	Kontaktboks stol arbeid Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus 24V	804489
216454	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus h20 1G	804491
216455	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus rotasjon h20 1G	804492
216456	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus h28 1G	804493
216457	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus rotasjon h28 1G	804494
216458	Batteri stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus Plus 24V	804496
216459	Aktuator stol arbeid Real 9100 Plus/9400/Real 9800 Plus elbrems elektronikk relekort	804498
216460	Aktuator stol arbeid Real 9100/Real 9400 Plus/Real 9800 Plus ryggvinkel releasats inkl elektronikk eksl ladeboks sett	804499
216461	Aktuator stol arbeid Real 9100 Plus/9400/Real 9800 Plus tilt releasats inkl elektronikk eksl ladeboks sett	804500
216462	Aktuator stol arbeid Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus tilt 24V	804501
216463	Aktuator stol arbeid Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus brems 24V	804502
216465	Sittekryss Mini stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	804509
216466	Sittekryss Jr stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	804512
216467	Sittekryss stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	804513
216468	Fotring stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus m	804515
216469	Holder stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus	804516
216471	Feste stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus sidebord b43 d33	804518
232903	Ladekontakt stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus m/kabel og feste	804550
251026	Benstøtte stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400 midtmontert øvre grunn I20-31 m/låsraff	804865
253250	Kontrollboks stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus 24V 1G	804572
264908	Skruer stol arbeid 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus M12 I1,25	801224
268777	Aktuator stol arbeid Real 9100 Plus/Real 9800 Plus tilt sittekryss vreg 15/8 24V 1G	804573
268778	Aktuator stol arbeid Real 9400 tilt 15/15 24V 1G	804636

268779	Bordplate stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus b43 d33 sidebord	802451
268780	Bordplate stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus b45 d37 klar med kanter	804370
268781	Bordplate stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus b60 d45 sotet med kanter	801374
268782	Bryter stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus u/tunge brems 24V 1G	804547
268783	Endehette stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/9400/Real 9700 Plus/Real 9800 Plus L-phono 24V 1G	804611
268784	Feste stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus bremsespak 2pos	805015
268785	Feste stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus bremsespak 7pos	805016
268786	Feste stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus styresystem 24V 1G	804558
268787	Festebånd stol Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus batteri i85 b1,8	804551
268788	Håndkontroll stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus 1 funksjon 24V 1G	804813
268789	Kabel stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus 6,3mm - 3,5mm	804855
268790	Kabel stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus L-phono til Molex 24V 1G	804812
268791	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus//Real 9400 Plus/Real 9700 Plus/Real 9800 Plus h15 1.5G 24V 1G	804912
268792	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus//Real 9400 Plus/Real 9700 Plus/Real 9800 Plus h20 1.5G 24V 1G	804913
268793	Løfteenhet stol arbeid Real 9000 Plus/Real 9100 Plus//Real 9400 Plus/Real 9700 Plus/Real 9800 Plus h28 1.5G 24V 1G	804914
268794	Klemme stol arbeid 9100 Plus/Real 9400 Plus/Real 9800 Plus plast løfteenhet el	801177
268795	Sittekruss Mini stol arbeid Real 9300 Plus/9400 b29-33 vreg -15grader/+15grader nedre 24V 1G	804562
268796	Sittekruss Mini stol arbeid Real 9300 Plus/9400 b29-33 vreg -15grader/+15grader øvre	804563
268797	Sittekruss stol arbeid Real 9000 Plus/Real 9100 Plus b40-54 24V 1G	804545
268798	Sittekruss stol arbeid Real 9000 Plus/Real 9100 Plus b40-54 vreg -15grader/+23grader 24V 1G	804506
268799	Sittekruss stol arbeid Real 9000 Plus/Real 9100 Plus b40-54 vreg 24V 1G	804504
268800	Sittekruss stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9800 Plus b40-54 vreg -15grader/+15grader nedre 24V 1G	804566
268801	Sittekruss stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9700 Plus/Real 9800 Plus b40-54 vreg -15grader/+15grader øvre	804567
268802	Sittekruss stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9700 Plus/Real 9800 Plus b40-54 vreg 24V 1G nedre	804514
268803	Sittekruss stol arbeid Real 9300 Plus/Real 9400 Plus b33-39 24V 1G	804546
268804	Sittekruss stol arbeid Real 9300 Plus/Real 9400 Plus b33-39 vreg -15grader/+23grader 24V 1G	804507
268805	Sittekruss stol arbeid Real 9300 Plus/Real 9400 Plus b33-39 vreg 24V 1G	804505
268806	Sittekruss stol arbeid Real 9300 Plus/Real 9400 Plus b33-39 vreg 24V 1G nedre	804544
268807	Sittekruss stol arbeid Real 9300 Plus/Real 9400 Plus b33-40 vreg -15grader/+15grader nedre 24V 1G	804564
268808	Sittekruss stol arbeid Real 9300 Plus/Real 9400 Plus b33-40 vreg -15grader/+15grader øvre	804565
268809	Sittekruss stol arbeid Real 9700 Plus/Real 9800 Plus b40-54 vreg 24V 1G	804508
268810	Sittekruss stol Real 9700 Plus/Real 9800 Plus b40-54 24V 1G	804595
268811	Skrue stol arbeid 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus M6 I2	802038
268812	Skrue stol arbeid 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus m6 I2,5	802039
268813	Skrue stol arbeid 9100 Plus/Real 9400 Plus/Real 9800 Plus M6 I2 FZB	801256
268814	Skrue stol arbeid 9100 Plus/Real 9400 Plus/Real 9800 Plus M6 I4	801253
268815	Spiralkabel stol arbeid Real 9000 Plus/Real 9100 Plus/Real 9300 Plus/Real 9400 Plus/Real 9700 Plus/Real 9800 Plus molex til molex 24V 1G	804817